


# **BLE\* / \*** **Broadband Line Extender**




## **Installation and Operation Manual**



## Caution

These servicing instructions are for use by qualified personnel only. To reduce the risk of electrical shock, do not perform any servicing other than that contained in the Installation and Troubleshooting Instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

## Special Symbols That Might Appear on the Equipment

	This symbol indicates that dangerous voltage levels are present within the equipment. These voltages are not insulated and may be of sufficient strength to cause serious bodily injury when touched. The symbol may also appear on schematics.
	The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important installation, servicing, and operating instructions in the documents accompanying the equipment.
	For continued protection against fire, replace all fuses only with fuses having the same electrical ratings marked at the location of the fuse.

## FCC Compliance

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the Installation Manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense. Any changes or modifications not expressly approved by Motorola could void the user's authority to operate this equipment under the rules and regulations of the FCC.

## Canadian Compliance

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.  
Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

<b>Declaration of Conformity</b>				
We		Motorola, Inc. 101 Tournament Drive Horsham, PA 19044, U.S.A.		
declare under our sole responsibility that the				
STARLINE		Model BLE*/*		
to which this declaration relates is in conformity with one or more of the following standards:				
<b>EMC Standards</b>				
EN55022	EN55024	EN50083-2	CISPR-22	CISPR-24
<b>Safety Standards</b>				
EN60065	EN60825	EN60950	IEC 60950 + A1: 1992 + A2: 1993 + A3: 1995 + A4: 1996	
following the provisions of the Directive(s) of the Council of the European Union:				
EMC Directive 89/336/EEC		Low Voltage Directive 73/23/EEC		

Copyright © 2001 by Motorola, Inc.

All rights reserved. No part of this publication may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation or adaptation) without written permission from Motorola, Inc.

Motorola reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of Motorola to provide notification of such revision or change. Motorola provides this guide without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Motorola may make improvements or changes in the product(s) described in this manual at any time.

---

The General Instrument logo, STARLINE, LIFELINE, and OmniStar are registered trademarks of General Instrument Corporation, a wholly-owned subsidiary of Motorola, Inc.

Motorola, and the stylized M logo, are registered trademarks of Motorola, Inc. All other product or service marks are the property of their respective owners.

# Contents

---

## Section 1

### Introduction

Using This Manual .....	1-3
Related Documentation.....	1-3
Document Conventions.....	1-3
If You Need Help.....	1-4
Calling for Repairs .....	1-4

## Section 2

### Overview

Configuration .....	2-2
Housing .....	2-3
Gaskets .....	2-4
Port Locations.....	2-5
Power Supplies .....	2-6
Standard Power Supply .....	2-6
Power Factor Corrected Power Supply .....	2-7
Forward Amplifier.....	2-7
Return Amplifier, RA-Kit/H or RA-Kit/L .....	2-8
Ingress Control Switch .....	2-8
Options and Accessories .....	2-9

## Section 3

### Amplifier Setup

Forward Path Alignment .....	3-1
Before You Begin .....	3-1
Cable Equalizer .....	3-1
Example 1.....	3-2
Example 2.....	3-2
Starline Cable Simulators.....	3-5
Input and Midstage Pads.....	3-6
Flatness Control .....	3-6
Directional Coupler Test Points .....	3-8
Bode Equalization .....	3-8
Amplifier Level Control.....	3-9
Manual Gain Control .....	3-9
Thermal Drive Unit .....	3-10

Automatic Drive Unit.....	3-11
ADU Pads and Levels.....	3-11
<b>Return Path Alignment</b>	
Before You Begin.....	3-12
Alignment Procedure .....	3-13
<b>Powering and Surge Protection .....</b>	<b>3-14</b>

## Section 4

### Bench Testing

<b>Before You Begin .....</b>	<b>4-1</b>
<b>Test Equipment and Connections .....</b>	<b>4-1</b>
Measuring Forward Gain.....	4-2
Example .....	4-2
Testing Return Gain and Response .....	4-3
Completing the Test Procedures .....	4-3

## Section 5

### Installation

<b>Aerial Installation.....</b>	<b>5-1</b>
<b>Pedestal Installation.....</b>	<b>5-3</b>

## Section 6

### Operating Tips

<b>Using the Midstage Pad .....</b>	<b>6-1</b>
-------------------------------------	------------

## Appendix A

### Specifications

<b>Model BLE87S/G* .....</b>	<b>A-1</b>
<b>Model BLE87S/* .....</b>	<b>A-2</b>
<b>Model BLE75S/G* .....</b>	<b>A-3</b>
<b>Model BLE75S/* .....</b>	<b>A-4</b>
<b>AC Current, BLE75*/*, BLE87*/* (Standard Power Supply).....</b>	<b>A-4</b>
<b>RA-Kit/L Return Amplifier .....</b>	<b>A-5</b>
<b>ADU Automatic Drive Unit .....</b>	<b>A-5</b>

## Appendix B

### Torque Specifications

### Abbreviations and Acronyms

## Figures

Figure 1-1 BLE*/* - closed .....	1-1
Figure 1-2 BLE*/* - open .....	1-2
Figure 2-1 BLE*/* line extender.....	2-1
Figure 2-2 BLE*/* configurator .....	2-2
Figure 2-3 BLE-HSG/15 housing.....	2-3
Figure 2-4 Housing gaskets.....	2-4
Figure 2-5 Housing ports .....	2-5
Figure 2-6 BLE*/* standard power supply .....	2-6
Figure 2-7 BLE*/* PFC power supply.....	2-7
Figure 2-8 BLE*/* block diagram .....	2-8
Figure 2-9 Location of options, pads, test points and accessories in the BLE*/* .....	2-11
Figure 3-1 Equalizer slope versus cable .....	3-4
Figure 3-2 Frequency versus cable slope.....	3-6
Figure 3-3 *LDR*/*/II component layout.....	3-7
Figure 3-4 Typical flatness and control ranges .....	3-8
Figure 3-5 TDU cable selector .....	3-10
Figure 3-6 ADU.....	3-11
Figure 4-1 Test equipment connections for bench sweeping .....	4-1
Figure 5-1 Center-conductor pin length .....	5-1
Figure 5-2 Torque sequence .....	5-2

## Tables

Table 2-1 Options and accessories for the BLE*/* .....	2-9
Table 3-1 Starline Forward Equalizers – SFE*-* .....	3-3
Table 3-2 Starline Cable Simulators.....	3-5
Table 3-3 Gain reserve versus ambient temperature .....	3-9
Table 3-4 BLE*/* AGC pad levels .....	3-12

## Section 1

# Introduction

---


The Motorola STARLINE® series of broadband line extenders, BLE\*/\*, accept a single input and provide 28 through 30 dB of operational gain (depending on model) to a single output. The high gain makes the BLE\*/\* series ideally suited for a hybrid fiber-coax system as well as conventional tree and branch designs. The BLE\*/\* series of line extenders comply with IEEE C62.41-1991 and Bell Core GR-1098 specifications for overvoltage testing as recommended by Cable Labs. The latest BLE\*/\* platform is also FCC and CE approved.

Features of the BLE\*/\* include:

- 750 MHz or 870 MHz power doubling technology in enhanced gallium arsenide (E-GaAs) or silicon
- Several different modular duplex filter splits
- “Ease of use” ergonomics
- 60/90 Vac line power option
- Thermal and auto-controlled Bode equalization
- -20 dB directional coupler test points
- Optional return path ingress control and LIFELINE® status monitor
- Two-way operation capability
- 15-amp power passing

Figure 1-1 illustrates a closed BLE\*/\* line extender:

**Figure 1-1**  
**BLE\*/\* - closed**







## Using This Manual

The following sections provide information and instructions to bench test, install, and operate the BLE\*/\*.

<b>Section 1</b>	<b>Introduction</b> provides a product description, related documentation, the technical helpline, and repair/return information.
<b>Section 2</b>	<b>Overview</b> describes the BLE*/* line extender and includes details on the various options and their functions.
<b>Section 3</b>	<b>Amplifier Setup</b> provides instructions for full configuration and forward- and return-path alignment.
<b>Section 4</b>	<b>Bench Testing</b> describes the bench test procedures that are recommended before installing the unit.
<b>Section 5</b>	<b>Installation</b> provides instructions for installing the BLE*/* and performing field alignment.
<b>Section 6</b>	<b>Operating Tips</b> provides suggestions for handling field-encountered variables and addressing maintenance tasks.
<b>Appendix A</b>	<b>Specifications</b> lists the applicable technical specifications for the BLE*/* and options.
<b>Appendix B</b>	<b>Torque Specifications</b> provides the appropriate torque specifications for the screws, clamps, connectors, and bolts used in the BLE*/*.
<b>Abbreviations and Acronyms</b>	The <b>Abbreviations and Acronyms</b> list contains the full spelling of the short forms used in this manual.

This installation manual assumes that all channels are standard National Television Standards Committee (NTSC) analog channels. Refer to catalog specifications for further details pertaining to signal levels of digital channels above 550 MHz.

This installation manual uses 870 MHz as the reference frequency unless another frequency is given. For example, quoted cable loss is understood to be at 870 MHz.

## Related Documentation

This installation manual is complete and you should not require any additional documentation to install, test, or operate the BLE\*/\* line extender.

## Document Conventions

Before you begin using the BLE\*/\*, familiarize yourself with the stylistic conventions used in this manual:

<b>SMALL CAPS</b>	Denotes silk screening on the equipment, typically representing front- and rear-panel controls, input/output (I/O) connections, and LEDs
<b>* (asterisk)</b>	Indicates that several versions of the same model number exist and the information applies to all models; when the information applies to a specific model, the complete model number is given
<i>Italic Type</i>	Used for emphasis

## If You Need Help

If you need assistance while working with the BLE\*/\* call the Motorola Technical Response Center (TRC):

- Inside the U.S.: **1-888-944-HELP (1-888-944-4357)**.
- Outside the U.S.: **215-323-0044**
- Online: <http://www.motorola.com/broadband>, click **HTML/Modem Version**, click **Customer Support**, then click **Web Support**.

The TRC is open from 8:00 AM to 7:00 PM Eastern Time, Monday through Friday and 10 AM to 6 PM Eastern Time, Saturday. When the TRC is closed, emergency service *only* is available on a call-back basis. Web Support offers a searchable solutions database, technical documentation, and low priority issue creation/tracking 24 hours per day, 7 days per week.

## Calling for Repairs

If repair is necessary, call the Motorola Repair Facility at **1-800-227-0450** for a Return for Service Authorization (RSA) number before sending the unit. The RSA number must be prominently displayed on all equipment cartons. The Repair Facility is open from 8:00 AM to 5:00 PM Central Time, Monday through Friday.

When calling from outside the United States, use the appropriate international access code, and then call **956-541-0600** to contact the Repair Facility.


When shipping equipment for repair, follow these steps:

- 1 Pack the unit securely.
- 2 Enclose a note describing the exact problem.
- 3 Enclose a copy of the invoice that verifies the warranty status.
- 4 Ship the unit **PREPAID** to the following address:

Motorola, Inc.  
c/o William F. Joffroy, Inc.  
Attn: RSA # \_\_\_\_\_  
1480 North Industrial Park Dr.  
Nogales, AZ 85621

\_\_\_\_\_

Table 1. The number of cases of *Brucella* spp. in the 1990s and 2000s in the Republic of Serbia, by sex and age group




## Configuration

The BLE\*\* is fully configured in the Motorola factory per customer request. It is recommended that you verify the configuration listed on the outside of the shipping carton with the configuration that you ordered. The shipped configuration is also noted in a label on the side of the RF chassis.

Figure 2-2 illustrates the BLE\*\* configuration notation:

**Figure 2-2**  
**BLE\*\* configurator**




## Housing

The BLE\*/\* is furnished in a BLE-HSG/15 aluminum housing that protects the electronics from weather and dissipates internally generated heat.

Figure 2-3 illustrates the BLE-HSG/15 housing and provides its dimensions:

**Figure 2-3**  
**BLE-HSG/15 housing**



Coaxial cable connections to the housing are made using conventional 5/8 inch  $\times$  24 threads per-inch stinger-type connectors. Four port plugs in the cover enable access to internal test points without opening the housing.

The BLE-HSG/15 differs from the housing of the 10A BLE\*/\* (model BLE-75SH and BLE-75JH) and the JLX series of line extenders. However, the 10A BLE\*/\* and the JLX series of line extenders can be upgraded to 15A amplifiers using existing housings with the BLE-15A

platform assembly kit (P/N 951941-006-00). The BLE-15A kit contains 15 A platform assemblies.


Two messenger clamps are cast in the top of the housing and are secured with 5/16 inch × 24 threads-per-inch stainless-steel bolts. The back of the housing also contains two 5/16 inch × 24 threaded holes located on the vertical center-line separated by four inches center-to-center. Use these holes and the bolts from the messenger clamps for pedestal and surface-mounting installations.

### **Gaskets**

Each housing is equipped with a recessed woven-wire RF gasket and a silicone-rubber gasket to provide a seal between the housing base and lid. These gaskets provide efficient ground continuity, RF shielding, and weather protection. Both gaskets must be in place and in good condition to ensure proper operation and protection of the station. The weather gasket should be lightly coated with silicone grease each time the BLE\*/\* is opened. Replace this gasket if it becomes damaged or deformed.

Figure 2-4 illustrates the housing gaskets:

**Figure 2-4**  
**Housing gaskets**




### Port Locations

Two housing ports provide connection for coaxial cables. Four port plugs in the cover enable access to internal test points. All ports are protected by factory-inserted threaded plugs or plastic cap plugs. Discard the plastic cap plugs when you install the cable connectors.

Figure 2-5 illustrates the housing port locations:

**Figure 2-5**  
**Housing ports**





## Power Supplies


The BLE\*/\* is available with a standard power supply or the optional power-factor-corrected (PFC) power supply. The following subsections describe and illustrate the differences.

### Standard Power Supply

The power supply of the BLE\*/\* is a separate circuit board mounted to the underside of the amplifier module and is capable of 60 Vac or 90 Vac powering. The power supply provides a regulated 24 Vdc output over an ac input between 38 V and 90 Vrms with a line frequency from 50 Hz through 60 Hz. Potentiometer R25 adjusts the output voltage to 24 Vdc, however, this is set at the factory and field adjustment is not recommended.

Figure 2-6 illustrates the components on the standard power supply circuit board:

**Figure 2-6**  
**BLE\*/\* standard power supply**



The power supply also contains a two position LO/HI selector that sets the *start-up voltage* for 38 Vac or 55 Vac. The BLE\*/\* is shipped with the selector in the LO position which is the standard configuration. The selector should be switched to the HI position only for a 90 Vac system. This sets the start-up voltage at 55 Vac. Because this is only 5 V below 60 Vac, it is not practical in a 60 Vac system. There is no damage to the amplifier if the selector is not changed from the standard LO setting. However, changing the selector ensures that the dc supply does not turn on until the proper input voltage, 38 Vac or 55 Vac, is reached. This prevents excessive loading of the system power supply during turn-on after a system shutdown.

The power supply includes a heavy-duty gas discharge tube which you can replace with the optional fast-transfer electronic-crowbar (FTEC) surge protector. The FTEC is a crowbar circuit that fires at approximately 245 V and presents a short circuit to the line during periods of overvoltage. After the ac input voltage returns to normal, the FTEC resumes its open state.


The factory-installed 20-ampere fuse, illustrated in Figure 2-9, provides power-passing to additional line extenders.

### Power Factor Corrected Power Supply

The PFC power supply is offered as a configured option in the BLE\*/\*. The PFC design lowers the current draw of the amplifier and improves power supply efficiency for the entire system. Information provided in the previous subsection, Standard Power Supply, is applicable to the PFC. R14 is the on-board 24 V adjustment which is set at the factory and should not require correction in the field.

Figure 2-7 illustrates the components on the PFC power supply circuit board:

**Figure 2-7**  
**BLE\*/\* PFC power supply**




### Forward Amplifier

The operational gain of the 750 MHz silicon version is 29 dB with 15 dB of return loss. The 870 MHz silicon version achieves 30 dB operational gain with a return loss of 15 dB. All E-GaAs BLE\*/\* amplifiers achieve 28 dB of gain with 16 dB of return loss. The operating gain includes provisions for the insertion loss of the input cable equalizer and required reserve gain to operate the Bode equalizer in the middle of its range. The low-noise figure, pre-amplifier stage, is a conventional 750 MHz (BLE75\*) or 870 MHz (BLE87\*) hybrid followed by a power-doubled output stage. Between the two stages is a JXP-\*T pad socket, the Bode board, and the flatness and equalizer board. Because these losses are located interstage, the noise figure is only impacted by the insertion loss of the forward cable equalizer or a broadband cable simulator.

Figure 2-8 illustrates the interconnection among these components:

**Figure 2-8**  
**BLE\*/\* block diagram**



## Return Amplifier, RA-Kit/H or RA-Kit/L

The circuit board of the forward amplifier accommodates the optional return amplifier. The return amplifier kit, model RA-Kit/H or RA-Kit/L, includes the return amplifier hybrid and jumpers. The standard circuit board contains all components including the diplex filters with extended return bandwidth for the amplifier input and output. All items are plug-in and easily installed. The input and output of the return amplifier include two JXP-\*T pad facilities. You can also use either pad socket as a test point or a signal injection point. The output pad value is normally selected to control the return signal level into the next upstream amplifier. Select an appropriate input pad to attenuate excessive input signal.

The return-input test point and the return-output test point are directional couplers. Both test points present 75-ohm source impedance and do not require special test probes.

## Ingress Control Switch

The ingress control switch (ICS) module provides return-path signal attenuation or cutoff in the BLE\*/\*. This is accomplished through the LIFELINE® status-monitoring module, LL-BLE-HMS. (Figure 2-9 illustrates the location of the optional ICS). The ICS provides a means of isolating sources of ingress from a centralized location. Using a downstream command through the

LIFELINE status-monitoring system, you can attenuate the return path through the line extender by 6 dB or by 38 dB. By reducing the ingress level at the headend or monitoring point, you can further isolate the ingress source. After an ingress source is isolated to the last possible amplifier, node, or line extender, you can shut the return path off at that location. This limits the impact of the ingress on the remainder of the network while eliminating the source of ingress.

## Options and Accessories

The factory ships the amplifier as a fully functional unit, but you must configure it appropriately for the field-location requirements. You must install the correct equalizer or broadband cable simulator to place the unit into service. Section 3, “Amplifier Setup” provides information to help you select the correct equalizer or broadband simulator. Use model JXP-\*T pads to control field signal levels. To compensate for temperature, install the automatic drive unit (ADU) or thermal drive unit (TDU) before placing the unit in service. You can install other items, such as a return amplifier and additional surge protection at your discretion, but these options do not render the unit inoperative if they are not included.


Table 2-1 provides a comprehensive list of options and accessories for the BLE\*/\* and Figure 2-9 illustrates their locations.

**Table 2-1**  
**Options and accessories for the BLE\*/\***

Model	Description	Function
<b>ADU</b>	Automatic Drive Unit	This board automatically controls amplifier output levels that change with cable attenuation and hybrid output. The selection of a pilot frequency is required.
<b>TDU</b>	Thermal Drive Unit	This board controls amplifier gain and slope for changes in cable attenuation for the sensed temperature.
<b>RA-Kit/H or L</b>	Return Amplifier Kit	This kit enables two-way operation and includes a high-or low-gain return hybrid and jumpers.
<b>SFE-0, SFE-1</b>	Starline Forward Equalizers	These equalizers are not bandwidth restricted and compensate for 0 dB and 1 dB of cable, respectively, from 5 MHz to 1 GHz.
<b>SFE-*-*</b>	Starline Forward Equalizer	This bandwidth specific (750 or 870 MHz) equalizer compensates for cable properties in 1 dB increments from 2 dB through 22 dB. The appropriate value must be installed. See the product catalog for additional information.
<b>SRE-*-*</b>	Starline Return Equalizer	This equalizer compensates for cable attenuation in 1 dB increments from 0 dB through 12 dB for S-split (2 dB increments for all other splits). The appropriate value must be installed. See the product catalog for additional information.
<b>SCS-*</b>	Starline Cable Simulator	This simulator compensates for cable properties. The appropriate value must be installed. See the product catalog for additional information.
<b>JXP-*T</b>	Fixed attenuator	This pad attenuates excessive input signal. It is available in 0.5 dB increments from 0 dB through 26 dB. The appropriate value must be installed.
<b>JXP-TH*T</b>	Thermal attenuators	This option compensates for gain changes with temperature in the return path.

Model	Description	Function
<b>FTEC</b>	Fast Transfer Electronic Crowbar	This option is used for overvoltage protection and replaces the existing surge protector.
<b>LL-BLE-HMS</b>	Status monitor module	This module enables monitoring of the unit's operating parameters by the LIFELINE status-monitoring system. This accessory also requires the deep housing cover.
<b>BLE, cover/status monitor</b>	Deep housing cover	This optional cover is required to contain the LIFELINE status monitor module.
<b>RCB87</b>	Response Correction Board	This optional board compensates for system roll-off at 870 MHz. The BLE*/* is shipped with a jumper in this location which you can replace when additional response correction is required.
<b>JXP-RPC</b>	Return Path Correction board	This optional board provides additional flatness response correction in the return path for systems that must meet especially stringent return path flatness requirements.
<b>ICS</b>	Ingress Control Switch	This option enables remote monitoring, isolation, and reduction of ingress on the return path by providing signal attenuation of 6 dB or cutoff of 38 dB typical. The unit is shipped with a jumper in this location.

**Figure 2-9**  
**Location of options, pads, test points and accessories in the BLE\*/\***



In the event of ADU or TDU board failure, you can select manual control of the Bode board. Figure 2-9 illustrates the main circuit board containing the MAN/AUTO jumper.

## Section 3

# Amplifier Setup

---

This section provides instructions for fully configuring the BLE\*/\* and describes the proper forward and return path alignment procedures.

## Forward Path Alignment

The following subsections describe the BLE\*/\* alignment procedures required for proper performance in the forward path.

### Before You Begin

Before you begin to set-up the amplifier and perform forward-path alignment, please read the following instructions and recommendations.

For proper forward alignment obtain:

- RF output levels and tilts of all BLE\*/\*s in the forward or return path
- RF input level for the BLE\*/\* being set up (from system design or as-built map)
- A carrier at the system's highest frequency. It can be modulated or continuous wave (CW) and should be inserted in the headend at standard video levels. This carrier is used to simplify field set-up.

It is recommended that you:

- *Remove the input pad and/or the SFE-\*-\* before you install or remove the electronics package (E-pack) or apply power to the BLE\*/\*.*
- Do not use wire jumpers to bypass the SFE-\*-\* location.
- Recognize that actual pad and SFE-\*-\* values may differ slightly from their design values. This is caused by factors such as walkout errors, worst-case data utilization during design and temperature variation from 70°F.
- Secure the E-pack in the housing and torque to 18-22 in-lbs. to facilitate heat transfer and avoid damage from overheating.
- Subject the BLE\*/\* to a 24-hour heat cycle before performing bench alignment.
- Do not daisy-chain power on burn-in racks.
- Perform a bench alignment. Pre-distorting the BLE\*/\* response on the bench (Section 4, "Bench Testing") for a system signature simplifies field alignment.
- Field sweep the entire bandwidth of the amplifier to correct frequency response for passive signature and roll-off.
- Close the housing in accordance with the instructions in Section 5, "Installation."

### Cable Equalizer

Select the appropriate Model SFE-\*-\* to compensate for cable attenuation versus frequency and to obtain the proper output tilt. The BLE\*/\* is equipped with the \*LDR\*/II interstage equalizer and flatness board, which compensates for cable attenuation. Any cable or passive slope beyond

that of the LDR must be compensated for by selecting and installing the appropriate SFE-\*. \* cable equalizer.

Equalizers are available in 1 dB steps from 0 dB through 22 dB. The following examples describe how to choose the correct equalizer.

#### Example 1

The BLE75/\* is used in a cascade of amplifiers which operate with 10 dB of cable. System records show that 20 dB of cable exists between the line extender and the previous unit.

To obtain the correct equalizer value, subtract 10 dB, the 7LDR/7/II equalizer value, from 20 and the result is the required equalizer (20 – 10 = 10). Therefore, the correct equalizer is a model SFE-75-10. When selecting an equalizer, choose the next lower value if the exact value is not available.

Install the proper cable equalizer. To obtain the required output tilt the minimum attenuation of the cable connected to the input is 10 dB (7 dB slope at 750 MHz).

#### Example 2

The BLE87/\* is used in a link following a fiber node with flat output. There is 16 dB of cable between the node and the line extender, plus passive losses which are assumed to be flat. Which is the proper equalizer to achieve the 10 dB of output tilt?

In this case, calculate the equalizer value by using the following method:

$$\text{SLOPE}_{\text{eq}} = \text{TILT}_{\text{out}} + \text{SIG}_{\text{lo}} - \text{SIG}_{\text{hi}} - \text{SLOPE}_{\text{ieq}}$$

where:

- $\text{SLOPE}_{\text{eq}}$  = required SFE-87 slope
- $\text{TILT}_{\text{out}}$  = required amplifier output tilt
- $\text{SIG}_{\text{lo}}$  = signal input level at channel 2
- $\text{SIG}_{\text{hi}}$  = signal input level at 870 MHz
- $\text{SLOPE}_{\text{ieq}}$  = interstage equalizer slope (8 dB)

From various references, such as manufacturer's catalogs, you can determine that 16 dB of cable at the operating frequency of 870 MHz is 4 dB of loss at 54 MHz. This suggests that the channel 2 signal input level to the line extender is 12 dB greater (16 – 4 = 12) at channel 2 than it is at 870 MHz. Our example assumes that the high-end frequency level into the amplifier is +15 dBmV.

Substituting this information in equation (1) provides the following result:

$$10.0 \text{ dB} + 27 \text{ dB} - 15.0 \text{ dB} - 8.0 \text{ dB} = 14 \text{ dB}$$

The slope of the required equalizer is 14 dB. Table 3-1 and Figure 3-1 show that 14 dB of slope is caused by approximately 18 dB of cable at 870 MHz. Therefore the correct equalizer is model SFE-87-18.




Table 3-1 helps you choose the correct equalizers and also lists insertion loss at various frequencies:

**Table 3-1**  
**Starline Forward Equalizers - SFE\*.\***

Equalizer Value	Equalizer Slope	Frequency (MHz) versus Insertion Loss (dB)							
		50	200	300	450	550	650	750	870
SFE-75-									
22	16.3	17.3	11.6	9.1	6.0	4.2	2.5	1.0	
20	14.8	15.8	10.7	8.4	5.5	3.9	2.4	1.0	
18	13.4	14.4	9.7	7.6	5.1	3.6	2.2	1.0	
16	11.9	12.9	8.7	6.9	4.6	3.3	2.1	1.0	
14	10.4	11.4	7.8	6.1	4.2	3.0	2.0	1.0	
12	8.9	9.9	6.8	5.4	3.7	2.7	1.8	1.0	
10	7.4	8.4	5.8	4.7	3.3	2.4	1.7	1.0	
8	5.9	6.9	4.9	3.9	2.8	2.1	1.6	1.0	
6	4.5	5.5	3.9	3.2	2.4	1.9	1.4	1.0	
4	3.0	4.0	2.9	2.5	1.9	1.6	1.3	1.0	
2	1.5	2.5	2.0	1.7	1.5	1.3	1.1	1.0	
SFE-87-									
22	16.7	17.7	12.4	10.0	7.1	5.4	3.9	2.5	1.0
20	15.2	16.2	11.4	9.2	6.5	5.0	3.6	2.3	1.0
18	13.7	14.7	10.3	8.4	6.0	4.6	3.4	2.2	1.0
16	12.1	13.1	9.3	7.6	5.4	4.2	3.1	2.1	1.0
14	10.6	11.6	8.2	6.7	4.9	3.8	2.8	1.9	1.0
12	9.1	10.1	7.2	5.9	4.3	3.4	2.6	1.8	1.0
10	7.6	8.6	6.2	5.1	3.8	3.0	2.3	1.7	1.0
8	6.1	7.1	5.1	4.3	3.2	2.6	2.0	1.5	1.0
6	4.6	5.6	4.1	3.5	2.7	2.2	1.8	1.4	1.0
4	3.0	4.0	3.1	2.6	2.1	1.8	1.5	1.3	1.0
2	1.5	2.5	2.0	1.8	1.6	1.4	1.3	1.1	1.0

Figure 3-1 shows the equalizer slope versus equalizer value information presented in Table 3-1 as a graph. The amount of cable equals the equalizer value.

**Figure 3-1**  
**Equalizer slope versus cable**



## Starline Cable Simulators

The Starline Cable Simulators, Model SCS-\*, are used in place of fixed equalizers in systems where the amplifiers are located close together. The simulators are designed to fit in the same location as the equalizers.


Table 3-2 helps you choose the correct simulators:

**Table 3-2**  
**Starline Cable Simulators**

SCS-*	1	2	3	4	5	6	7	8	9	10
Frequency	Cable slope in dB									
40 MHz	0.0	0.1	0.1	0.1	0.2	0.2	0.3	0.3	0.3	0.4
45 MHz	0.0	0.0	0.1	0.1	0.1	0.1	0.1	0.1	0.2	0.2
50 MHz	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
72 MHz	-0.1	-0.2	-0.2	-0.3	-0.4	-0.4	-0.5	-0.6	-0.7	-0.7
108 MHz	-0.1	-0.3	-0.4	-0.5	-0.6	-0.8	-0.9	-1.0	-1.2	-1.3
150 MHz	-0.2	-0.5	-0.7	-0.9	-1.2	-1.4	-1.6	-1.9	-2.1	-2.3
211 MHz	-0.3	-0.7	-1.0	-1.4	-1.7	-2.1	-2.4	-2.8	-3.1	-3.5
250 MHz	-0.4	-0.8	-1.2	-1.7	-2.1	-2.5	-2.9	-3.3	-3.7	-4.1
300 MHz	-0.5	-1.0	-1.5	-1.9	-2.4	-2.9	-3.4	-3.9	-4.4	-4.9
350 MHz	-0.6	-1.1	-1.7	-2.2	-2.8	-3.3	-3.9	-4.4	-5.0	-5.5
400 MHz	-0.6	-1.2	-1.8	-2.5	-3.1	-3.7	-4.3	-4.9	-5.5	-6.2
450 MHz	-0.7	-1.4	-2.0	-2.7	-3.4	-4.1	-4.7	-5.4	-6.1	-6.8
550 MHz	-0.8	-1.6	-2.4	-3.2	-4.0	-4.8	-5.5	-6.3	-7.1	-7.9
750 MHz	-1.0	-2.0	-3.0	-4.0	-5.0	-6.0	-7.0	-8.0	-9.0	-10.0
870 MHz	-1.1	-2.2	-3.3	-4.4	-5.5	-6.7	-7.8	-8.9	-10.0	-11.1
50 MHz loss (typical)	-1.0	-1.0	-1.0	-1.0	-1.0	-1.0	-1.0	-1.0	-1.0	-1.0

The information in Table 3-2 is shown as a graph in Figure 3-2:

**Figure 3-2**  
**Frequency versus cable slope**



## Input and Midstage Pads

Install Model JXP-<sup>®</sup>T pads to attenuate the signal per system design drawings. Generally, this consists of attenuating excessive input levels. You should pad the input to achieve unity gain. Select and install the specified pad in the socket labeled JXP-IN on the chassis cover. The midstage pad (JXP-MID) normally remains at 0 dB but can be used to adjust the gain level and achieve the gain specification. Refer to Section 6, “Operating Tips,” for midstage padding information and recommendations.

## Flatness Control

The <sup>®</sup>LDR/<sup>®</sup>II circuit board includes flatness controls and a fixed cable equalizer for 750 MHz or 870 MHz. This equalizer, plus the contribution of the hybrid gain stages, produces approximately the dB of slope indicated by the model number (8 dB of tilt with an <sup>®</sup>LDR/8/II).

The <sup>®</sup>LDR/<sup>®</sup>II variable resistors and capacitors can be adjusted to flatten the response from marker 1 to marker 4 as illustrated in Figure 3-4. Use C1, C2, R1, and R2 on the LDR board shown in Figure 3-3 for low-end flatness response (marker 1 to marker 2). The low-end flatness controls compensate for the roll-off caused by the diplex filters. Adjust C3 and R3 for a flat response around 400 MHz (between marker 2 and 3). Adjust C7, C8, and R8 for a flat response across the band (marker 1 to marker 4). Adjust C6 for maximum gain at the high end (marker 3 to marker 4).

- C1 produces a peak that is centered just below the lowest forward frequency and varied in amplitude by R1.
- C2 produces a peak that is centered at approximately 100 MHz and varied in amplitude by R2.

- C3 produces a peak that is centered at approximately 400 MHz and varied in amplitude by R3.

Air coils on the bottom of the \*LDR\*/II board may slightly tune the upper portion of the response.

**Figure 3-3**  
**\*LDR\*/II component layout**





Figure 3-4 illustrates BLE87\* flatness and control ranges:

**Figure 3-4**  
Typical flatness and control ranges



### Directional Coupler Test Points

Accurate 20 dB directional-coupler test points are available at the input and at the output of the BLE\*/\*. Because these test points are 75-ohm source impedance, they do not require special test probes.

After the output hybrid, a second directional coupler provides signal to the optional ADU board. This signal is used only when the ADU board is installed. It is not necessary to terminate this port when the ADU is not installed.

### Bode Equalization

The Bode board, which is an electronically controlled equalizer, receives its control input from either the ADU or TDU control boards. The response of the Bode board compensates for cable attenuation changes due to temperature. If necessary, you can control the Bode board manually using the potentiometer labeled MANUAL LEVEL in Figure 2-9.

## Amplifier Level Control

Signal levels vary in a cable system primarily because cable attenuation changes with temperature. Other components such as passives and amplifier hybrids are also affected by temperature changes. To automatically compensate for these signal level fluctuations and control output level, you must select the optional ADU or TDU. When necessary and appropriate, you can also use manual gain control.

### Manual Gain Control

To use manual gain control:

- 1 Install the E-pack.
- 2 Ensure that there is continuity in the forward path by installing the design-value input equalizer and design value input JXP-\*T attenuators.
- 3 Ensure that the drive control select jumper is in the MAN position.
- 4 Use a signal-level meter to measure the high band-edge carrier input level at the input test point: 750 MHz = channel 116, 870 MHz = channel 136.

This carrier should be at standard analog level, non-scrambled.

- 5 Verify that the input level agrees with the design specification input.

If the level is different from design, adjust accordingly. For example: the design level is 19 dBmV at the highest frequency and the design pad value is JXP-3T. If the actual measured level is 21 dBmV, then you must change the pad to a JXP-5T.

If the actual levels are significantly different from the design levels, it is recommended that you investigate or consult system management before proceeding.

- 6 Connect the signal-level meter to the output test point and tune the meter to the high-end channel. Turn the manual gain reserve (MAN) control (illustrated in Figure 2-9) to maximum (fully clockwise) and then reduce the output as noted in Table 3-3 below:

**Table 3-3**  
**Gain reserve versus ambient temperature**

Temperature	Gain Reserve
Above 110°F (43°C)	3 dB
32°F (0°C) to 110°F (43°C)	4 dB
Below 32°F (0°C)	5 dB

- 7 Check the amplifier output tilt by measuring the high band- and low band-edge carriers.
  - High = channel 116 (745.25 MHz) or channel 136 (865.25 MHz)
  - Low = channel 2 (55.25 MHz) or channel 3 (61.25 MHz)
  - If the tilt is less than required, install a higher value input equalizer
  - If the tilt is greater than required, install a lower value input equalizer
  - If the high value equalizer provides too much tilt and the low value equalizer provides too little tilt, use the lower value equalizer. Under-equalization is preferred to over-equalization.

If you use an SCS cable simulator and the design value is changed, you must also adjust the input pad. For each 1 dB increase in SCS value, 1 dB of loss is introduced at 750 MHz or 1.1 dB of loss at 870 MHz. Therefore, to maintain a proper gain level, it is necessary to adjust the input pad value as follows:

- For each increase in SCS value, decrease the input pad by 1 dB for the BLE75\* or 1.1 dB for BLE87\*. Pads are available in 0.5 dB increments, therefore, use to closest value possible.
  - For each decrease in SCS value, increase the input pad by 1 dB for the BLE75\* or 1.1 dB for BLE87\*.
  - If you replace an SFE with an SCS, reduce the value of the input pad by the value of the SCS for the BLE75\* or a good estimate for the BLE87\*. Use the 1 dB loss at 750 MHz to 1.1 dB loss at 870 MHz ratio to be exact.
- 8 Measure the output level at the highest frequency. It should be within 1 dB of the system design level. If it is not, change the input pad (JXP IN) to a higher or lower value to achieve the proper level. The midstage pad (JXP MID) normally remains at 0 dB, but can be used to adjust the gain level and achieve the gain specification. Refer to Section 6, "Operating Tips," for midstage padding information and recommendations.


### Thermal Drive Unit

The TDU senses temperature and controls the Bode board. It is assumed that the cable is subjected to the same or similar temperature, therefore, the TDU should not be used for underground installations.

To set-up the TDU:

- 1 Place the jumper on the TDU (Figure 3-5) to the LOW, MEDIUM, or HIGH position to specify the amount of cable for which the TDU compensates at the highest frequency preceding the BLE\*/\* station. Low = 0 dB to 15 dB of cable, medium = 15 dB to 30 dB, and high = 30 dB or more of cable.

**Figure 3-5**  
**TDU cable selector**



- 2 Position the drive control select jumper (Figure 2-9) temporarily in the MAN position and perform the complete procedure described in Manual Gain Control if not already completed.
- 3 Position the drive control select jumper to AUTO.



- 4 Connect a signal-level meter to the FWD OUT test point and tune the meter to the high band-edge carrier.
- 5 Turn the thermal level potentiometer on the TDU fully clockwise and then reduce to obtain the level obtained in Step 3 under Manual Gain Control.

### Automatic Drive Unit

The ADU operates by using surface acoustic wave (SAW) filters to select a pilot frequency and then monitors the amplitude of this frequency. Any change in signal level is fed back to the Bode equalizer. It is assumed that the encountered signal level changes are due to changes in cable attenuation and hybrid output associated with a change in temperature. The Bode equalizer then changes its insertion loss to maintain a constant output level. The ADU (illustrated in Figure 3-6) maintains the most precise output level of the three available methods.

**Figure 3-6**  
**ADU**



To set-up the ADU:

- 1 Position the drive control select jumper temporarily to the MAN position and perform the complete procedure described in Manual Gain Control if not already completed.
- 2 Verify that the frequency stamped on the ADU control unit is the same as the system pilot frequency. The pilot frequency is a CW or an available NTSC television channel not scrambled using sync suppression and not a digital channel.
- 3 Position the drive control select jumper to AUTO.
- 4 Connect a signal-level meter to the FWD OUT test point and tune the meter to the high band-edge carrier.
- 5 Turn the auto level control potentiometer (ADU) (illustrated in Figure 2-9) fully clockwise and then reduce to obtain the level obtained in Step 3 under Manual Gain Control.

### ADU Pads and Levels

This subsection provides information regarding the proper ADU padding requirements for the BLE\*/\*.

A JXP-ZXT pad is installed in the input line to the ADU location. This pad adjusts the ADU input level for the standard application of the BLE\*/\*. This pad can be changed depending on the operational output of the BLE\*/\*. In general, a JXP-6T pad is recommended in the BLE\*/\* ADU circuit. This is the standard pad value as shipped from the factory and is appropriate for an amplifier output level range from +42 dBmV to +50 dBmV at 550 MHz.

Table 3-4 provides the AGC pad values for other output levels. Recommended pad values are shaded.

**Table 3-4**  
**BLE\*/\* AGC pad levels**

BLE*/*	ADU Control Range (dBmV)		
	Minimum Level at 547.25 MHz	Midpoint Level at 547.25 MHz	Maximum Level at 547.25 MHz
-	35	39	43
<b>0</b>	36	40	44
<b>1</b>	37	41	45
<b>2</b>	38	42	46
<b>3</b>	39	43	47
<b>4</b>	40	44	48
<b>5</b>	41	45	49
<b>6</b>	42	46	50
<b>7</b>	43	47	51
<b>8</b>	44	48	52
<b>9</b>	45	49	53
<b>10</b>	46	50	54
<b>11</b>	47	51	55
<b>12</b>	48	52	56
<b>13</b>	49	53	57

The use of the ADU or TDU is recommended for improved output level stability although you can operate the BLE\*/\* in the manual mode. Select manual mode by placing the drive control select jumper, illustrated in Figure 2-9, in the MAN position. The gain of the BLE\*/\* is then determined by the potentiometer marked MAN on the amplifier cover.

## Return Path Alignment

The following subsections describe the BLE\*/\* alignment procedures required for proper performance in the return path.

### Before You Begin

Before you begin to set-up the amplifier and perform return-path alignment, please read the following instructions and recommendations.

For proper return alignment obtain:

- RF alignment levels and insertion points for all BLE\*/\*s
- RF reference output level of the headend optical receivers

Equipment required for return-path alignment includes:

- Full complement of JXP-TH pads and Starline return equalizers (SRE-TH)
- Reverse signal generator — must produce at least one signal within the return bandpass and have variable output
- Return sweep or alignment equipment

It is recommended that you:

- Do not use wire jumpers to bypass the SRE-TH location
- Perform the return optical link set up before performing amplifier set up
- Specify reverse alignment design levels for a single carrier
- Consider sweep equipment as a single carrier and operate at design levels
- Do not include injection point losses in reverse design levels

If JXP THERM devices (JXP-TH) are specified for level control, they should be installed in the JXP THERM pad facility (illustrated in Figure 2-9) after alignment has been performed.

### Alignment Procedure

The return amplifier configuration includes one low-gain (25 dB) or one high-gain (30 dB) return amplifier hybrid, and an appropriate SRE-TH equalizer. All components are plug-in and are easily installed.

To align the return path:

- 1 If the BLE is powered, remove all fuses before you perform the following steps.
- 2 Carefully install a reverse hybrid amplifier, if necessary, and install the design value pad and equalizer in the output locations.
- 3 Ensure that both hybrid screws are tight. Torque the screws to 10 to 12 in-lbs. Over torque can damage the hybrid.
- 4 Verify that there is a 0 dB pad (JXP-ZXT jumper) installed in the return input pad location (JXP-IN).

If the optional ICS was ordered, verify that it is in the ICS location. If it was not ordered, the factory installed jumper should remain in the ICS location.

- 5 Verify that the output pad closest to the hybrid output (JXP-OUT) has a 0 dB pad (JXP-ZXT jumper) installed.
- 6 Verify that the output pad socket (JXP THERM), located between the hybrid output and the SRE-TH, has a 0 dB pad (JXP-ZXT jumper) or a JXP-TH installed.
- 7 Set the sweep equipment output level to the amplifiers design input level. Add insertion point loss.
- 8 If required, change the output pad and/or equalizer to achieve, as close as possible, a match of the reference level as compared to the node.
- 9 Verify the sweep response of all insertion points if applicable.
- 10 Verify that the pad and equalizer values are similar to the map design values.

You can verify proper return alignment by injecting a carrier, at the design level, into any amplifier at random. Proper alignment is achieved if you observe the reference level at the headend optical receiver output.

Return levels used for alignment are not necessarily operational system levels. These levels vary from system to system due to differences in equipment, architectures and design philosophies. For an in-depth analysis and discussion of the return path, refer to Motorola reference guide *Return Path Level Selection, Setup and Alignment Procedure*.

## Powering and Surge Protection

In conventional applications, the line extenders are powered through the input port. *To avoid damage to the hybrids, it is recommended that you remove the input pad (JXP-IN) before you apply power to the BLE\*/\*. A 20-ampere, blade-type fuse is furnished in the amplifier module and provides overcurrent protection for ac power applied to the input. You can power the BLE\*\* from the output without passing power through to the input port. To block power from the input port, remove the power-block jumper illustrated in Figure 2-9.*

### WARNING!



To avoid possible injury to personnel or damage to the equipment, remove 60/90 volt ac power from the system before you remove any components from the housing.

The BLE\*\* is shipped from the factory configured for 38 through 90 Vac powering as described in Section 2, “Overview”. To configure the line extender for 55 Vac through 90 Vac operation:

- 1 Remove the E-pack from the housing.
- 2 Remove the power-supply cover.
- 3 Move the LO/HI selector (jumper J1 on the power-supply board) from the LO to HI position. Figure 2-6 illustrates the jumper location.
- 4 Re-install the power-supply cover and torque the screws to 10 to 12 in-lbs.
- 5 Re-install the E-pack in the housing and torque the hold-down bolts to 18 to 22 in-lbs.

Standard surge protection is provided in the power supply by a heavy-duty, 230-volt, gas discharge surge protector. As an option, you can install the FTEC crowbar overvoltage protector. The FTEC, which replaces the standard gas-discharge tube, has a firing potential of approximately 245 volts.

To install the FTEC:

- 1 Remove the E-pack from the housing.
- 2 Remove the power-supply cover.
- 3 Remove the gas-tube surge protector, illustrated in Figure 2-6.
- 4 Replace it with the FTEC.
- 5 Re-install the power-supply cover and torque the screws to 10 to 12 in-lbs.
- 6 Re-install the E-pack in the housing and torque the hold-down bolts to 18 to 22 in-lbs.

## Section 4

# Bench Testing

---

Motorola's recommended procedure for placing a new BLE\*/\* into service is to fully test it on the bench before it is field installed. There are specific alignment procedures that ensure proper functioning of all components and simplify final installation. If the BLE\*/\* is properly aligned on the bench only minor adjustments may be required in the field.

The following subsections provide instructions to bench align the BLE\*/\*.

## Before You Begin

The BLE\*/\* is shipped with a 20 ampere blade-type fuse for overcurrent protection. *To avoid applying 60/90 Vac to the test equipment during testing, remove the fuse illustrated in Figure 2-9.*


Open the housing and remove the chassis cover. Refer to your system drawings or records to confirm the presence of the required options as described in Section 3, "Amplifier Setup," Forward Path.

## Test Equipment and Connections

The equipment typically used for testing the BLE\*/\* consists of a network analyzer such as the HP 8711, 8712 or 8713 series, a model 1076 sweep comparator, and a model 1901C display or equivalent. In addition, you need a 60/90 Vac bench power supply, a Motorola model SSP-PIN power combiner, and a variety of jumper cables, adapters, and fittings.

Fabricate a cable simulator that you can configure to provide the desired cable loss in 1 dB increments up to approximately 30 dB. Then, connect the test equipment as shown in Figure 4-1:

**Figure 4-1**  
Test equipment connections for bench sweeping



*To protect the network analyzer and sweep comparator, you must configure the SSP-PIN power combiner to block ac power from the input port.*

## Measuring Forward Gain

This subsection provides instructions for measuring the full gain and the operational gain and flatness of the BLE\*/\*.

To measure the full gain of the amplifier:

- 1 Determine whether the power-supply jumper (J1) is positioned for LO or HI operation.
- 2 *Remove the input pad (JXP-IN) before you apply power to avoid damage to the hybrids.*
- 3 Connect the BLE\*/\* to the test equipment as illustrated in Figure 4-1 and apply power.
- 4 Verify that the B+ voltage is  $24\text{ V} \pm 0.4\text{ V}$  and re-install the input pad.
- 5 Apply the sweep signal and adjust test equipment as needed.
- 6 Select manual gain by placing the drive control select jumper in the MAN position and turn the MANUAL LEVEL control (Figure 2-9) fully clockwise.
- 7 Measure the gain at mixed forward frequency using the procedure outlined in the operator manual provided with the test equipment in use. To correct this number, add the insertion loss of the SSP-PIN power combiner (0.5 dB at 550 MHz, 0.6 dB at 750 MHz, or 0.7 dB at 870 MHz), the loss of the cable simulator at mixed forward frequency, and the loss of the cable equalizer (1.0 dB), if it is installed.

### Example

The test equipment indicates a measured gain of 12.5 dB with a BLE75S/\* and the cable simulator is set to 20 dB.

$$\begin{aligned}
 &0.8\text{ dB (power combiner)} \\
 &+ 1.0\text{ dB (cable equalizer)} \\
 &+ 20.0\text{ dB (cable simulator)} \\
 &+ \underline{12.5\text{ dB (measured gain)}} \\
 &34.3\text{ dB (unit gain).}
 \end{aligned}$$

The result must meet advertised specifications for the unit.

The operational gain of the BLE\*/\* provides reduced gain capability. This enables the unit to operate in the proper region of the Bode board when it is controlled by the ADU or TDU drive units.

To measure the operational gain and flatness of the amplifier:

- 1 Perform steps 1 through 6 in Measuring Forward Gain above.
- 2 Estimate the ambient temperature and find the required gain reserve by referring to Table 3-3. Reduce the gain at the highest frequency by the amount given in the table.

Example:

The ambient temperature is 70°F. The table indicates that the required gain reserve is 4 dB. Reduce the gain by 4 dB.

The operational gain is the sum of the measured gain after performing Step 2, plus all losses, such as power combiner, cable loss, equalizer, and cable simulator.

The sweep response is essentially flat at this point. If the response exhibits tilt, the cable equalizer must be changed. Install a higher equalizer value if the gain is greater at the low frequencies; install the next lower equalizer value if the gain is less at the low-end frequencies.

- 3 Measure the gain excursions from an average value within the bandpass. The result is the peak-to-valley flatness. Some improvement is possible by adjusting the flatness controls on the \*LDR\*/II board as described in Section 3, "Amplifier Setup," Flatness Control. Figure 3-3 illustrates the location of these controls on the \*LDR\*/II board.

## Testing Return Gain and Response

After configuring the return path, you can test the return bandpass to ensure compliance with specifications. When testing the return amplifier, remember that it is a flat amplifier. Therefore, the cable simulator must remain in the test set-up and must remain set to the same cable equivalent as in the forward sweep test. This provides an approximate indication of the frequency response, which you can achieve in the field.

To test for return gain and response:

- 1 Reconnect the test equipment and switch the *sweep input* and *sweep output* leads of the BLE\*/\* under test to be opposite of the connection shown in Figure 4-1.
- 2 Remove the power block and replace the 20 A fuse (both illustrated in Figure 2-9) before you apply power.
- 3 Re-adjust the test equipment to sweep from 4 MHz through the maximum return band frequency plus 10 MHz.

The expected response is flat. Any tilt, which is due to the return equalizer, must average out to a flat response in a cascade of amplifiers. A slope adjustment is not available in the return bandpass.

- 4 Measure the gain at the maximum return band frequency (e.g. 40 MHz for S-split). The amplifier gain is the sum of: the measured gain, the insertion loss of the return cable equalizer at the maximum return band frequency, the insertion loss of the power combiner, any pads installed in either the input or output pad locations, plus the cable simulator loss at the maximum return band frequency. The measured gain must meet advertised specifications for the return amplifier.

Example

14.0 dB (measured gain)  
 + 1.0 dB (equalizer insertion loss)  
 + 0.8 dB (power combiner)  
 + 0.0 dB (pads)  
+ 4.6 dB (cable simulator at 40 MHz)  
 20.4 dB (unit gain)

## Completing the Test Procedures

The amplifier is now approximately tailored for a specific field location. Additional adjustments after installation are minor in nature. Re-install the fuse removed during testing.

Complete station records by recording pertinent information. Remove test-equipment connections and close the housing following instructions provided in Section 5, "Installation," Closing the Housing.



## Section 5

# Installation

---


The field installation procedures presented in the following subsections assume that the amplifier was previously tested and bench aligned. Cable power and RF signal must be available on the system. Although it is desirable to have a full complement of channels available for balancing, you can adjust the BLE\*/\* adequately with a limited number of channels.

You can install the BLE-HSG/15 on a messenger strand or on a pedestal. The following subsections provide details on the application you require.

## Aerial Installation

The housing is normally mounted without the E-pack to avoid possible damage during installation. Connections are made using standard pin-type connectors with a nominal center-conductor diameter of 0.067 inches. The minimum length of the center-conductor pin is 1.5 inches and the maximum length is 1.65 inches. Longer pins can extend past the center-conductor seizure mechanism and degrade the match. Extremely long pins can result in a short circuit.

**Figure 5-1**  
**Center-conductor pin length**



To install the unit:

- 1 Power down the cable before you install the housing. This avoids blown fuses, tripped circuit breakers, and possible personal injury.
- 2 Mount the housing, and torque the 5/16-inch messenger clamp bolts to 10 to 12 ft-lbs. Form the customary expansion loops and make all cable connections.
- 3 To avoid water ingress, ensure that aluminum connectors are torqued to the specifications recommended by the connector manufacturer.
- 4 Tighten the center-conductor seizure screw using a Phillips-head screw driver. An alternate method is to use a 3/16-inch socket and a torque wrench. The recommended torque is 12 in-lbs. maximum.
- 5 Re-install the electronics and fasten the module to the housing with the four captive bolts. Torque to 18 to 22 in-lbs.
- 6 *Remove the input pad (JXP-IN) to avoid damage to the hybrids.*
- 7 Apply power to the unit and allocate a few minutes for warm up.


- 8 Check the ac voltage setting (jumper J1, Figure 2-6).

J1 position	Description
-------------	-------------

LO	The voltage must be greater than 38 Vac as read with a true rms voltmeter or 42 Vac when using a conventional, average reading, ac voltmeter.
HI	The voltage must be greater than 55 Vac when read with a true rms voltmeter or 61 Vac when using a conventional, average reading, ac voltmeter.

- 9 Check the dc voltage. Verify that it is between 23.6 V and 24.4 V and reinstall the input pad.
- 10 If necessary, rebalance the amplifier following the instructions in Section 3, "Amplifier Setup."
- 11 Check the tightness of the chassis cover screws (10 to 12 in-lbs.) and E-pack hold-down bolts (18 to 22 in-lbs.).
- 12 Check the condition of the RF and weather gaskets.
- 13 Close the housing and use a torque wrench to sequentially and progressively tighten the housing bolts to a final torque of 6 ft-lb in the sequence specified on the housing cover and illustrated in Figure 5-2.

**Figure 5-2**  
**Torque sequence**



## Pedestal Installation

Mount the BLE\*/\* to the pre-drilled pedestal mounting plate. Use the 5/16-inch messenger clamp bolts to mount the unit to the pedestal and torque to 10 to 12 in-lbs.

Pedestal installation is similar to the aerial installation with one exception—temperature. In an aerial installation, the cable and amplifier are subject to the same temperature. In contrast, pedestal installation provides a stable temperature environment for the buried cable while subjecting the elevated amplifier to higher temperatures. The ADU, if installed, functions the same as in an aerial installation, and does not require further attention.

Manual thermal compensation provided by the TDU can be inaccurate and result in signal level changes with ambient temperature change. One approach to this problem is to select the least amount of cable setting (low) on the TDU. This results in minimal gain change with temperature. A preferred approach is to install a JXP-TH\*T thermal attenuator while operating the BLE\*/\* in the manual mode.

## Section 6

# Operating Tips

---

When using the BLE\*/\* in 750 MHz or 550 MHz systems, you must consider the best method for handling the reduced bandwidth and channel-loading requirement. The following information helps you determine the best approach.

For distribution systems designed and installed as 870 MHz systems, but carrying a reduced channel load, there are no further concerns. You can add or remove channels at your discretion. If the system operates with ADUs, the pilot channel cannot be disturbed. Reduced channel loading improves distortion.

For lower-frequency systems, such as 750 MHz or 550 MHz, to maintain amplifier gain it is optimal to use the amplifier and equalizers that match the system frequency. For example, 750 MHz equalizers used in 550 MHz systems, result in reduced amplifier gain. In the BLE\*/\* the SFE, as well as the LDR, are designed and optimized to a specific passband. When possible, in addition to using the equalizers that correspond to your system frequency, also install the amplifiers designed for that frequency. For example, in a 750 MHz system, a 750 MHz amplifier is preferred but not required.

## Using the Midstage Pad

There are two pad facilities in the forward amplifier. One is the conventional pad location at the input to the amplifier (JXP-IN) and the other location is between the pre-amplifier and the output stage (JXP-MID).

The input pad (JXP-IN) is normally changed to accommodate excessive input levels. When operating at the same output levels, a BLE\*/\* with an input pad has the same carrier-to-noise (c/n) and distortion performance as a BLE\*/\* without the input pad. Because it only attenuates excess signal, it has no effect on the overall performance of the BLE\*/\*.

You can use the midstage pad (JXP-MID) to reduce the gain of the BLE\*/\* with minimal impact to the noise figure, thus improving the c/n performance. There is a penalty, however, for using this technique. When operating at the same output levels, the midstage pad forces the pre-amplifier to operate at a higher output level. This degrades the station distortion performance. Depending on: (1) the specific parameter being considered (CTB, CSO, XMD, noise figure), (2) operating variables such as output level, and (3) the amplifier configuration, distortion degradation can range from 0.5 dB to 1.5 dB for each dB of attenuation added.

Operating conditions that require the use of the midstage pad are very rare. It is recommended that you contact Motorola's TRC or your account representative for specific information regarding use of the midstage pads.

## Appendix A

# Specifications

---

Specifications are valid over the given bandpass and operating temperature range of  $-40^{\circ}\text{F}$  to  $+140^{\circ}\text{F}$  ( $-40^{\circ}\text{C}$  to  $+60^{\circ}\text{C}$ ). Specifications are stated typical unless otherwise noted, and are subject to change. Refer to the Motorola BCS web site or contact your account representative for the latest specifications.

## Model BLE87S/G\*

Specification	Forward Amplifier		
<b>Bandpass</b>			
BLE87S/G*	52 through 870 MHz		
<b>Gain</b>			
Full	32 dB (with SFE-**-*)		
Operational	28 dB (with SFE-**-* and slope reserves)		
<b>Flatness</b>			
52 through 870 MHz	$\pm 0.60$ dB maximum		
<b>Level control, automatic</b>	Bode board using ADU/TDU		
<b>Gain control</b>	Fixed pads, JXP-*T		
<b>Performance - reference frequency (MHz)</b>	870/750/52	870/550/52	870/550/52
at typical output (dBmV)	43/47/37	47.5/48.5/41.5	43/44/37
Channels	112 analog/120 MHz digital (suppressed by 6 dB)	79 analog/320 MHz digital (suppressed by 6 dB)	79 analog/320 MHz digital (suppressed by 6 dB)
Crossmod (worst case)	-59 dB	-54 dB	-63 dB
CTB (worst case)	-65 dB	-63.5 dB	-74 dB
CSO (worst case)	-68 dB	-69.5 dB	-74 dB
<b>Noise figure</b>			
at 52 MHz	9 dB (with SFE-1)		
at 870 MHz	9 dB (with SFE-1)		
<b>Interstage equalizer, 8LDR/8/G/II</b>	$8 \pm 1$ dB		
<b>Hum modulation</b>	-70 dB		
<b>Return loss, input/output</b>	16 dB at operational level		
<b>Test points, input/output</b>	$20 \pm 0.7$ dB		
<b>Housing dimensions</b>	10.6 L $\times$ 8.0 W $\times$ 4.7 D inches (26.9 $\times$ 20.3 $\times$ 11.9 cm)		
<b>Weight</b>	7.2 pounds (3.2 kg)		

## Model BLE87S/ \*

Specification	Forward Amplifier	
<b>Bandpass</b>		
BLE87S/*	52 through 870 MHz	
<b>Gain</b>		
Full	34 dB (with SFE-*-* )	
Operational	30 dB (with SFE-*-* and slope reserves)	
<b>Flatness</b>		
52 through 870 MHz	±0.60 dB maximum	
<b>Level control, automatic</b>	Bode board using ADU/TDU	
<b>Gain control</b>	Fixed pads, JXP-*T	
<b>Performance - reference frequency (MHz)</b>	870/750/52	870/550/52
at typical output (dBmV)	43/47/37	43/44/37
Channels	112 analog/120 MHz digital (suppressed by 6 dB)	79 analog/320 MHz digital (suppressed by 6 dB)
Crossmod (worst case)	–58 dB	–63 dB
CTB (worst case)	–61 dB	–70 dB
CSO (worst case)	–66 dB	–73 dB
<b>Noise figure</b>		
at 52 MHz	9 dB (with SFE-1)	
at 870 MHz	9 dB (with SFE-1)	
<b>Interstage equalizer, 8LDR/8/II</b>	8 ±1 dB	
<b>Hum modulation</b>	–70 dB	
<b>Return loss, input/output</b>	15 dB at operational level	
<b>Test points, input/output</b>	20 ±0.7 dB	
<b>Housing dimensions</b>	10.6 L × 8.0 W × 4.7 D inches (26.9 × 20.3 × 11.9 cm)	
<b>Weight</b>	7.2 pounds (3.2 kg)	

## Model BLE75S/G\*

Specification	Forward Amplifier		
<b>Bandpass</b>			
BLE75S/G*	52 through 750 MHz		
<b>Gain</b>			
Full	32 dB (with SFE-**-*)		
Operational	28 dB (with SFE-**-* and slope reserves)		
<b>Flatness</b>			
52 through 870 MHz	±0.60 dB maximum		
<b>Level control, automatic</b>	Bode board using ADU/TDU		
<b>Gain control</b>	Fixed pads, JXP-**T		
<b>Performance - reference frequency (MHz)</b>	750/52	750/550/52	750/550/52
at typical output (dBmV)	47/37	45.5/48.5/41.5	41/44/37
Channels	112 analog	79 analog/200 MHz digital (suppressed by 6 dB)	79 analog/200 MHz digital (suppressed by 6 dB)
Crossmod (worst case)	-59 dB	-54 dB	-63 dB
CTB (worst case)	-65 dB	-63.5 dB	-74 dB
CSO (worst case)	-68 dB	-69.5 dB	-74 dB
<b>Noise figure</b>			
at 52 MHz	9 dB (with SFE-1)		
at 750 MHz	9 dB (with SFE-1)		
<b>Interstage equalizer, 7LDR/7/G/II</b>	7 ±1 dB		
<b>Hum modulation</b>	-70 dB		
<b>Return loss, input/output</b>	16 dB at operational level		
<b>Test points, input/output</b>	20 ±0.5 dB		
<b>Housing dimensions</b>	10.6 L × 8.0 W × 4.7 D inches (26.9 × 20.3 × 11.9 cm)		
<b>Weight</b>	7.2 pounds (3.2 kg)		

## Model BLE75S/ \*

Specification	Forward Amplifier	
<b>Bandpass</b>		
BLE75S/*	52 through 750 MHz	
<b>Gain</b>		
Full	33 dB (with SFE-*.*)	
Operational	29 dB (with SFE-*.*) and slope reserves)	
<b>Flatness</b>		
52 through 750 MHz	±0.60 dB maximum	
<b>Level control, automatic</b>	Bode board using ADU/TDU	
<b>Gain control</b>	Fixed pads, JXP-*.T	
<b>Performance - reference frequency (MHz)</b>	750/52	750/550/52
at typical output (dBmV)	47/37	37/44/37
Channels	112 analog	79 analog/200 MHz digital (suppressed by 6 dB)
Crossmod (worst case)	-59 dB	-63 dB
CTB (worst case)	-57 dB	-69 dB
CSO (worst case)	-59 dB	-68 dB
<b>Noise figure</b>		
at 52 MHz	9 dB (with SFE-1)	
at 750 MHz	9 dB (with SFE-1)	
<b>Interstage equalizer slope, 7LDR/7/II</b>	7 ±1 dB	
<b>Hum modulation</b>	-70 dB	
<b>Return loss, input/output</b>	15 dB at operational level	
<b>Test points, input/output</b>	20 ±0.5 dB	
<b>Housing dimensions</b>	10.6 L × 8.0 W × 4.7 D inches (26.9 × 20.3 × 11.9 cm)	
<b>Weight</b>	7.2 pounds (3.2 kg)	

## AC Current, BLE75\*/\*, BLE87\*/\* (Standard Power Supply)

AC Voltage	One-way (typical E-GaAs)	With RA-Kit (typical E-GaAs)	One-way (typical Silicon)	With RA-Kit (typical Silicon)
90 Vac	0.48 A	0.56 A	0.45 A	0.54 A
75 Vac	0.50 A	0.59 A	0.48 A	0.57 A
60 Vac	0.56 A	0.65 A	0.53 A	0.63 A
53 Vac	0.60 A	0.70 A	0.57 A	0.68 A
45 Vac	0.67 A	0.78 A	0.63 A	0.74 A
38 Vac	0.75 A	0.88 A	0.72 A	0.85 A



## RA-Kit/L Return Amplifier

Parameter	Specification
Bandpass	
BLE*/*	5 through 40 MHz
Gain, station (minimum)	19 dB (18 dB for M-split, 16 dB for T-split)
Flatness	±0.50 dB
Level control	Fixed pads, JXP-*T, input and output
Performance	
at typical output	41 dBmV, flat
Channels	4 NTSC
Crossmod	−74 dB
Single triple beat	−82 dB
Single second order	−77 dB
Noise figure	6 dB
Power requirements	24 Vdc, 125 mA

## ADU Automatic Drive Unit

Parameter	Specification
Pilot channel	See current catalog
Adjacent channel frequency	±6 MHz
Minimum BLE*/* output at pilot frequency	+36 dBmV
ALC stiffness	±0.3 output change for ±3.0 dB input change
Power requirement	24 Vdc, 75 mA

## Appendix B

# Torque Specifications

---

Torque specifications are valid for all models of the BLE\*/\*\*.

Fastener	Screw Size	Wrench Size	In-lbs	Torque	
				Ft-lbs	N-M
Strand clamp/pedestal mounting	5/16-18	1/2 inch	120-144	10-12	13.6-16.3
Housing/lid closure	1/4-20	7/16 inch	72	6.0	8.1
Test point plugs	5/8-24	1/2 inch	25-40	2.1-3.3	2.8-4.5
Seizure screw	#8-32	3/16 inch or Phillips	12	1.0	1.4
Hybrid	#6-32	Phillips	10-12	0.8-1.0	1.1-1.4
Chassis (E-pack)	#10-32	5/16 inch	18-22	1.5-1.8	2.0-2.4
Chassis cover	#6-32	1/4 inch or Phillips	10-12	0.8-1.0	1.1-1.4
Status monitor	#10-32 triple lead	5/16 inch	24-30	2.0-2.5	2.7-3.4
Power supply cover	#6-32	Phillips	10-12	0.8-1.0	1.1-1.4

## Abbreviations and Acronyms

---

The abbreviations and acronyms list contains the full spelling of the short forms used in this manual.

<b>ADU</b>	Automatic Drive Unit
<b>c/n</b>	carrier-to-noise
<b>CSO</b>	Composite Second Order
<b>CTB</b>	Composite Triple Beat
<b>cw</b>	Continuous wave
<b>dB</b>	Decibel
<b>dBmV</b>	Decibels referenced to one millivolt
<b>FTEC</b>	Fast Transfer Electronic Crowbar
<b>ICS</b>	Ingress Control Switch
<b>MHz</b>	Megahertz
<b>NTSC</b>	National Television Standards Committee
<b>rms</b>	root-mean-square
<b>RSA</b>	Return for Service Authorization
<b>SAW</b>	Surface Acoustic Wave
<b>SCS-*</b>	Starline Cable Simulator
<b>SFE-*-*</b>	Starline Forward Equalizer
<b>SRE-*-*</b>	Starline Return Equalizer
<b>TDU</b>	Thermal Drive Unit



**MOTOROLA**

475100-001-99  
8/01

